

BACKRACK™

FUNCTION AND STYLE FOR TODAY'S TRUCKS

Canadian Tire Application Chart

APPLICATION	BACKRACK™ #	CTC FRAME #	CTC MOUNT KIT #	TOOLBOX BRKT #
CHEV / GMC				
2008 - 2009 Fullsize New Body Style	10519	34-8015	Mount Kit Not Required	91010 / 34-8025
1999 - 2007 Fullsize Classic Body Style	10509	34-8008	Mount Kit Not Required	91010 / 34-8025
1988 - 1998 Fullsize CK Series	10503	34-8002	Mount Kit Not Required	91010 / 34-8025
1968 - 1987 Fullsize Old Body Style	10504	34-8003	Mount Kit Not Required	91010 / 34-8025
2004 - 2009 Compact Colorado / Canyon	10316	34-8018	Mount Kit Not Required	91010-C / 34-8028
1985 - 2005 Compact S10 / S15	10312	34-8011	Mount Kit Not Required	91010-C / 34-8028
FORD				
2004 - 2009 Fullsize F-150, 6.5 & 8ft Bed	10512	34-8017	Mount Kit Not Required	91013 / Special Order
2004 - 2009 Fullsize F-150, Supercrew 5.5 ft Bed	10512 SC	Special Order	Mount Kit Not Required	91010-C / 34-8028
1999 - 2009 Superduty	10501	34-8000	Mount Kit Not Required	91011 / 34-8026
1997 - 2003 Fullsize F-150, 6.5 & 8ft Bed	10502	34-8001	Mount Kit Not Required	91012 / 34-8027
1997 - 2003 Fullsize F-150, Supercrew 5.5 ft Bed	10502 SC	34-8016	Mount Kit Not Required	91010-C / 34-8028
1975 - 1996 Fullsize F-150, 8ft Bed Only	10506	34-8005	Mount Kit Not Required	91010 / 34-8025
1975 - 1996 Fullsize F-150, 6.5ft Bed Only	10505	34-8004	Mount Kit Not Required	91010 / 34-8025
1993 - 2009 Compact Ranger	10311	34-8010	Mount Kit Not Required	91010 / 34-8025
DODGE				
2002 - 2009 Fullsize Ram	10517	34-8086	Mount Kit Not Required	91010 / 34-8025
1994 - 2001 Fullsize Ram	10507	34-8006	Mount Kit Not Required	91010 / 34-8025
1963 - 1993 Fullsize Ram	10504	34-8003	Mount Kit Not Required	91010 / 34-8025
2005 - 2009 Compact Dakota	10314	34-8019	Mount Kit Not Required	91010-C / 34-8028
1987 - 2004 Compact Dakota	10313	34-8012	Mount Kit Not Required	91010-C / 34-8028
TOYOTA				
2008 - 2009 Fullsize Tundra New Body Style	10518	34-8087	Mount Kit Not Required	91010 / 34-8025
1995 - 2007 Fullsize Tundra	10508	34-8007	Mount Kit Not Required	91010 / 34-8025
1993 - 1998 Fullsize T-100	10508	34-8007	Mount Kit Not Required	91010 / 34-8025
2005 - 2009 Compact Tacoma	10317	Special Order	Mount Kit Not Required	Special Order
1997 - 2004 Compact Tacoma	10313	34-8007	Mount Kit Not Required	91010-C / 34-8028
MAZDA				
1993 - 2009 Compact B Series	10311	34-8010	Mount Kit Not Required	91010 / 34-8025
NISSAN				
2004 - 2009 Fullsize Titan	10511	34-8020	Mount Kit Not Required	91010 / 34-8025
2005 - 2009 Compact Frontier	10314	34-8019	Mount Kit Not Required	91010-C / 34-8028
1987 - 2004 Compact	10312	34-8012	Mount Kit Not Required	91010-C / 34-8028