

# BACKRACK™

FUNCTION AND STYLE FOR TODAY'S TRUCKS

## Application Chart

YEAR/MAKE & MODEL	BACKRACK™	BACKRACK™ (With Toolbox)	SAFETYRACK	SAFETYRACK (With Toolbox)	REAR BAR	TOOLBOX BRACKET <i>If sold separately. No hardware.</i>	TONNEAU COVER ADAPTORS
<b>CHEV / GMC</b>							
2007-11 Chev/GMC Silverado, Sierra (New Body)	10519	10519 TB	10500 + 30119	10500 + 30119 TB	11519	91010	92519
1999-07 Chev/GMC Classic	10509	10509 TB	10400 + 30109	10400 + 30109 TB	11509	91010	92509
1988-98 Chev/GMC CK Series	10503	10503 TB	10400 + 30103	10400 + 30103 TB	11503	91010	92001
1968-87 Chev/GMC	10504	10504 TB	10400 + 30103	10400 + 30103 TB	11504 C	91010	92001
2004-08 Colorado / Canyon	10316	10316 TB **	10200 + 30116	10200 + 30116 TB		91010-C	
1985-05 S10, S15	10312	10312 TB **	10200 + 30113	10200 + 30113 TB		91010-C	
<b>DODGE</b>							
2002-11 Dodge Ram 1500 / 2500 8' Box	10517	10517 TB	10400 + 30117	10400 + 30117 TB	11517	91010	92517
2009-11 Dodge Ram 1500 5.5' Box	10527	10527 TB	10400 + 30127	10400 + 30127 TB	11527	91010	92517
2009 Dodge Ram 1500 6.5' Box	10537	10527 TB	10400 + 30137	10400 + 30127 TB	11527	91010	92517
2010-11 Dodge Ram 6.5' Bed	10517	10517 TB	10400 + 30117	10400 + 30117 TB	11517	91010	92517
2002-2008 Dodge Ram (All Lengths)	10517	10517 TB	10400 + 30117	10400 + 30117 TB	11517	91010	92517
1994-01 Dodge Ram	10507	10507 TB	10400 + 30107	10400 + 30107 TB	11507	91010	92001
1968-87 Chev/GMC	10504	10504 TB	10400 + 30103	10400 + 30103 TB		91010	92001
2005-11 Dakota	10314	10314 TB **	10200 + 30113	10200 + 30113 TB		91010-C	
1987-04 Dakota	10313	10313 TB **	10200 + 30113	10200 + 30113 TB		91010-C	
<b>FORD</b>							
1999-11 Superduty	10501	10501 TB	10300 + 30201	10300 + 30201 TB	11501	91011	92501
2004-11 Ford F-150 ( No Supercrew )	10512	10512 TB	10500 + 30112	10500 + 30112 TB	11512	91013	92512
2004-11 Ford F-150 5.5 ft bed only	10512 SC	10512 SCTB	10500 + 30104	10500 + 30104 TB		91010-C	
1997-03 Ford F-150 ( No Supercrew )	10502	10502 TB	10400 + 30102	10400 + 30102 TB	11502	91012	
1997-03 Ford F-150 Supercrew	10502 SC	10502 SCTB	10400 + 30104	10400 + 30104 TB		91010-C	
1975-96 Ford F-150 8 ft only	10506	10506 TB	10400 + 30106	10400 + 30106 TB	11506	91010	92001
1975-96 Ford F-150 6.5 ft only	10505	10506 TB	10400 + 30105	10400 + 30105 TB	11506	91010	92001
1993-11 Ford Ranger	10311	10311 TB **	10200 + 30111	10200 + 30111 TB	11310 R	91010	92001
<b>TOYOTA</b>							
2008-11 TUNDRA	10518	10518 TB	10500 + 30118	10500 + 30118 TB	11518	91010	92001
2005-11 TACOMA	10317	10317 TB	10200 + 30317	10200 + 30317 TB			
1995-07 TUNDRA	10508	10508 TB	10400 + 30108	10400 + 30108 TB	11508	91010	92001
1995-04 TACOMA	10313	10313 TB **	10200 + 30113	10200 + 30113 TB		91010-C	
<b>MAZDA</b>							
1993-11 Mazda	10311	10311 TB **	10200 + 30111	10200 + 30111 TB	11310 R	91010	92001
<b>NISSAN</b>							
2004-11 Nissan Titan	10511	10511 TB	10400 + 30511	10400 + 30511 TB		91010	92001
2005-11 Nissan Frontier	10314	10314 TB **	10200 + 30113	10200 + 30113 TB		91010-C	
1987-04 Compact	10312	10312 TB **	10200 + 30113	10200 + 30113 TB		91010-C	